

ELECTRIC VACUUM PUMP KIT



When using a supercharger or a big cam, chances are there's not enough vacuum being generated to operate power brakes. At least 16" of vacuum is needed to properly run a power brake booster. Our new vacuum pump kit will provide the proper amount of vacuum.

Kit includes: 12 volt vacuum pump, switching relay, vacuum line and control, mounting insulators and hardware.



800.448.7722
www.ssbrakes.com

Proud Members:

